




SERIES ARD100/ARD200




Mtrl.nr: 9814 09 62 • Ritn.nr 8473 vers. A • Rev 1512



Series ARD100
Series ARD200

CE
LVD 2006/95/EC valid until April 19th 2016
LVD 2014/35/EU valid from April 20th 2016
EMC 2004/108/EC valid until April 19th 2016
EMC 2014/30/EU valid from April 20th 2016
RoHS 2011/65/EU












Series ARD100



Series ARD200





Series 3F, 4F



Valve settings



V 1A

R/CW





V 1B

L/CCW





V 2A

R/CW



V 2B



L/CCW



Valve settings



V 3A

R/CW





V 3B

L/CCW





V 4A

R/CW




V 4B

L/CCW




Valve Assembly


**V
5**




**V
6**



**V
7**




**V
8**



Actuator Settings Valve Assembly

**V
9A**

= 90°




**V
9B**


Limiting working range • Clockwise working direction (R/CW)



Open position




Example R/CW working range 0° - 75°



i

ARD169/
ARD269
Dip Switch 4






**V
9C**


Limiting working range • Counter clockwise working direction (L/CCW)

Max working range
0° – 90°


Min working range
0° – 48°



Open
position



Exampel L/CCW working range 0°- 75°



i

ARD169/
ARD269
Dip Switch 4






Manual operation


**V
10A**



**V
10B**



**V
10C**



**V
11**  **i**

ARD100/ARD200
Electrical
Settings

