




**SERIES ARD100/ARD200**




Mtrl.nr: 9814 09 62 • Ritn.nr 8473 vers. A • Rev 1512



Series ARD100  
Series ARD200

CE  
LVD 2006/95/EC valid until April 19th 2016  
LVD 2014/35/EU valid from April 20th 2016  
EMC 2004/108/EC valid until April 19th 2016  
EMC 2014/30/EU valid from April 20th 2016  
RoHS 2011/65/EU











Series ARD100



Series ARD200




Series 3F, 4F



## Valve settings


**V 1A**

R/CW




**V 1B**

L/CCW




**V 2A**

R/CW



**V 2B**


L/CCW



## Valve settings


**V 3A**

R/CW




**V 3B**

L/CCW




**V 4A**

R/CW




**V 4B**

L/CCW




## Valve Assembly


**V  
5**




**V  
6**



**V  
7**




**V  
8**



## Actuator Settings Valve Assembly

**V  
9A**

= 90°




**V  
9B**


Limiting working range • Clockwise working direction (R/CW)



Open position




Example R/CW working range 0° - 75°



**i**

ARD169/  
ARD269  
Dip Switch 4






**V  
9C**


Limiting working range • Counter clockwise working direction (L/CCW)

Max working range  
0° – 90°


Min working range  
0° – 48°



Open  
position



Exampel L/CCW working range 0°- 75°



**i**

ARD169/  
ARD269  
Dip Switch 4






Manual operation


**V  
10A**



**V  
10B**



**V  
10C**



**V  
11**



**i**

**ARD100/ARD200**  
Electrical  
Settings

